

# Required Radio Channels for WCRG Excursions

Association of American Railroads (AAR) Radio Channel/Frequency Chart							
AAR Channel	Mhz		AAR Channel	Mhz		AAR Channel	Mhz
005	160.185		030	160.560		055	160.935
006	160.200		031	160.575		056	160.950
007	160.215		032	160.590		057	160.965
008	160.230		033	160.605		058	160.980
009	160.245		034	160.620		059	160.995
010	160.260		035	160.635		060	161.010
011	160.275		036	160.650		061	161.025
012	160.290		037	160.665		062	161.040
013	160.305		038	160.680		063	161.055
014	160.320		039	160.695		064	161.070
015	160.335		040	160.710		065	161.085
016	160.350		041	160.725		066	161.100
017	160.365		042	160.740		067	161.115
018	160.380		043	160.755		068	161.130
019	160.395		044	160.770		069	161.145
020	160.410		045	160.785		070	161.160
021	160.425		046	160.800		071	161.175
022	160.440		047	160.815		072	161.190
023	160.455		048	160.830		073	161.205
024	160.470		049	160.845		074	161.220
025	160.485		050	160.860		075	161.235
026	160.500		051	160.875		076	161.250
027	160.515		052	160.890		077	161.265
028	160.530		053	160.905		078	161.280
029	160.545		054	160.920		079	161.295
							<b>WCRG</b> Channels
						Channel	Mhz
						WCRG-1	151.625
						WCRG-2	151.505
						WCRG-3	151.700

(Note: Channel WCRG-3 not currently required)