

# Required Radio Channels for WCRG Excursions

## Association of American Railroads (AAR) Radio Channel/Frequency Chart

| AAR<br>Channel | Mhz     |  | AAR<br>Channel | Mhz     |  | AAR<br>Channel | Mhz     |  | AAR<br>Channel           | Mhz     |
|----------------|---------|--|----------------|---------|--|----------------|---------|--|--------------------------|---------|
| 005            | 160.185 |  | 030            | 160.560 |  | 055            | 160.935 |  | 080                      | 161.310 |
| 006            | 160.200 |  | 031            | 160.575 |  | 056            | 160.950 |  | 081                      | 161.325 |
| 007            | 160.215 |  | 032            | 160.590 |  | 057            | 160.965 |  | 082                      | 161.340 |
| 008            | 160.230 |  | 033            | 160.605 |  | 058            | 160.980 |  | 083                      | 161.355 |
| 009            | 160.245 |  | 034            | 160.620 |  | 059            | 160.995 |  | 084                      | 161.370 |
| 010            | 160.260 |  | 035            | 160.635 |  | 060            | 161.010 |  | 085                      | 161.385 |
| 011            | 160.275 |  | 036            | 160.650 |  | 061            | 161.025 |  | 086                      | 161.400 |
| 012            | 160.290 |  | 037            | 160.665 |  | 062            | 161.040 |  | 087                      | 161.415 |
| 013            | 160.305 |  | 038            | 160.680 |  | 063            | 161.055 |  | 088                      | 161.430 |
| 014            | 160.320 |  | 039            | 160.695 |  | 064            | 161.070 |  | 089                      | 161.445 |
| 015            | 160.335 |  | 040            | 160.710 |  | 065            | 161.085 |  | 090                      | 161.460 |
| 016            | 160.350 |  | 041            | 160.725 |  | 066            | 161.100 |  | 091                      | 161.475 |
| 017            | 160.365 |  | 042            | 160.740 |  | 067            | 161.115 |  | 092                      | 161.490 |
| 018            | 160.380 |  | 043            | 160.755 |  | 068            | 161.130 |  | 093                      | 161.505 |
| 019            | 160.395 |  | 044            | 160.770 |  | 069            | 161.145 |  | 094                      | 161.520 |
| 020            | 160.410 |  | 045            | 160.785 |  | 070            | 161.160 |  | 095                      | 161.535 |
| 021            | 160.425 |  | 046            | 160.800 |  | 071            | 161.175 |  | 096                      | 161.550 |
| 022            | 160.440 |  | 047            | 160.815 |  | 072            | 161.190 |  | 097                      | 161.565 |
| 023            | 160.455 |  | 048            | 160.830 |  | 073            | 161.205 |  | <b>WCRG<br/>Channels</b> |         |
| 024            | 160.470 |  | 049            | 160.845 |  | 074            | 161.220 |  |                          |         |
| 025            | 160.485 |  | 050            | 160.860 |  | 075            | 161.235 |  | Channel                  | Mhz     |
| 026            | 160.500 |  | 051            | 160.875 |  | 076            | 161.250 |  | WCRG-1                   | 151.625 |
| 027            | 160.515 |  | 052            | 160.890 |  | 077            | 161.265 |  | WCRG-2                   | 151.505 |
| 028            | 160.530 |  | 053            | 160.905 |  | 078            | 161.280 |  | WCRG-3                   | 151.700 |
| 029            | 160.545 |  | 054            | 160.920 |  | 079            | 161.295 |  |                          |         |

(Note: Channel WCRG-3 not currently required)